

WELCOME...

To the happy family of satisfied electronic musical instrument owners! To get the most out of the many features and functions of the keyboard, please be sure to read carefully this manual and keep it at hand for future reference.

MAIN FEATURES

- Strong multifunctional LCD system with large-screen display in many languages, which makes selecting and editing parameters much easier.
- 348 different kinds of voices, including 25 voices of Chinese folk instruments(Trichord, Gu-Zheng, Erhu, Suona)
- Almost including 100 popular accompaniment styles in the world. Each has its own intro and main (A, B two types), variation and ending.
- 32 types of commonly-used voices and 32 types of commonly-used styles for rapid choice.
- With 9 groups of percussion instrument and a group of Chinese traditional percussion instrument.
- Great combination with direct selection and digital search.
- Graceful piano shape design and soft LCD back light makes the piano more luxurious.
- Be able to synthesize certain digital effects like the reverb、 chorus、 and 3 D stereo effect, which could create various sound field effects.
- Be able to record at most 5 user songs, and they could be played repeatedly.
- 22 demonstration songs, making great contributions to lifting your performance level.
- Panel-register function could save your beloved panel, and recall it whenever you want.

CONTENTS

Safety Precautions	P. 2	■ SYNCHRO Start	P. 16
Panel Controls and Terminals	P. 6	■ SYNCHRO Stop	P.19
Preparations	P. 9	■ Accompaniment Sections (Main A/B & fill-ins)	P. 20
■ Setting up	P. 9	Using Auto Accompaniment	
■ Connections	P. 9	Multi fingering	P.21
● Headphone and Audio Output	P. 9	Percussion	P.23
● MIDI Input and Output	P. 9	■ Keyboard Percussion	P.23
Playing the Piano	P. 10	■ Metronome	P.23
■ Starting to Play the Piano	P.10	Saving Songs	P.24
■ DEMO Songs	P.10	Song Recording	P.25
● Playing all Songs	P.10	■ Recording a User Song	P.25
● Playing a Single Selected Song	P.10	■ Song Clear	P.28
■ Voice	P.10	■ Track Clear	P.29
● Playing Voices	P.10	■ Playing a Song	P.30
■ Dual Voice	P.11	■ A-B repeat	P.31
● Balancing the Dual	P.11	Registration Memory	P.33
■ Control and Effect	P.11	■ Recording a Registration Memory Preset	P.33
● ReverbPitch bend Roller	P. 12	■ Recalling a Registration Memory Preset	P.34
● Footswitch	P.12	MIDI Functions	P.35
● Touch Respond	P. 12	■ What Is MIDI?	P.35
● Reverb	P.12	■ MIDI Functions	P.36
● Chorus	P. 12	■ Connecting to a PC	P.37
● Tuning	P.13	Appendix	P.38
● Transpose	P.13	Voice List	P.38
● Harmony	P.13	Style List	P. 40
● Minus Channel	P. 13	Drum Set Table	P.41
Accompaniment Style	P.14	Function Parameters	P. 43
■ Selecting a Style	P.14	Troubleshooting	P.44
■ Adjusting the Accompaniment Volume	P.14	Technique Specifications	P.45
■ Adjusting the Accompaniment Tempo	P. 14		
■ Playing the Accompaniment	P.15		

Safety Precautions...

■ Symbols

Various symbols are used in this user's manual guide and on the product itself to ensure that the product is used safely and Correctly, and to prevent injury to the user and other person as well as damage to property. Those symbols along with their Meanings are shown below.

■ **WARNING!**

This indication stipulates matters that have the risk of causing death or serious injury if the product is operated incorrectly while ignoring this indication.

■ **CAUTION!**

This indication stipulates matters that have the risk of causing injury as well as matters for which there is the likelihood of occurrence of physical damage only if the product is operated incorrectly while ignoring this indication.

■ Symbol Examples

 This triangle symbol means that the user should be careful. (The example at left indicates electrical shock caution.)

 This circle with a line through it means that the indicated action must not be performed. Indications within or nearby this symbol are specifically prohibited. (The example at left indicates that disassembly is prohibited.)

 The black dot means that the indicated action must be performed. Indications within this symbol are actions that are specifically instructed to be performed. (The example at left indicates that the power plug must be unplugged from the electrical socket.)

—————  ! WARNING —————

■ Please use caution regarding the handling of the AC adaptor.

- Do not use a voltage other than the indicated power supply voltage. Use of a voltage other than that indicated may cause fire or electrical shock.

- If the power cord should become damaged (expose wired, disconnection, etc.), purchase a new AC adaptor. Use of a damaged power cord may cause fire or electrical shock.

- Do not cut or damage the power cord. Also do not place heavy objects on top of it or subject it to excessive heat.

Damage to the power cord may cause fire or electrical shock.

- Do not attempt to shape the power cord or subject it to excessive bending, twisting or pulling. This may cause fire or electrical shock.

- Please use the adaptor specified for this instrument. Use if another adaptor may cause fire, electrical shock, or malfunction.

- **Do not locate the instrument or its stand on an uneven or unstable surface.**

- * Locating the instrument or its stand on an uneven or unstable surface can cause it to fall, creating the danger of personal injury.

- **Do not place containers containing water or other liquids on the instrument.**

- Do not place the following objects on the instrument. Placing such objects on the instrument may cause fire or electrical shock if they fall and get inside the instrument.



- Containers filled with water or other liquids (including vases, potted plants, cups, cosmetics and medicines)

- Small metal objects (including hairpins, sewing needles and coins)

- Flammable objects

In the event a foreign object should happen to get inside the instrument, please take the following actions:

1. Turn power off.



2. Unplug the AC adaptor from the wall outlet.

3. If there are any batteries loaded in the keyboard, remove them.

- * Do not touch the batteries directly with your hands when removing them. They may be hot or battery fluid may be leaking from them.

4. Consult with the dealer where you purchase the keyboard or with an authorized service provider.

- **Do not disassemble or modify the instrument.**



Never attempt to take apart or modify the instrument, its accessories, or separately sold options. Doing so may cause fire, electrical shock or malfunction. Consult your dealer concerning all inspection, adjustment or repair of internal components.

- **Do not use if there is an abnormality or malfunction.**



- * Do not use the instrument if there appear to be abnormalities such as the presence of smoke or abnormal odor. Also do not use the instrument if there appear to be malfunctions such as the power not coming on or sound not being produced. Use under such conditions may cause fire or electrical shock. In such cases, take the following actions immediately. Never attempt to repair the instrument yourself.

1. Turn power off.



2. Unplug the AC adaptor from the wall outlet.

3. If there are any batteries loaded in the keyboard, remove them.

- * Do not touch the batteries directly with your hands when removing them. They may be hot or battery fluid may be leaking from them.

4. Consult with the dealer where you purchased the keyboard or with an authorized service provider.

- **When the instrument has been dropped:**



- * In the case the instrument has been dropped or damaged, take the following actions. Continued use may cause fire or electrical shock.

1. Turn power off.



2. Unplug the AC adaptor from the wall outlet.

3. If there are any batteries loaded in the keyboard, remove them.

- * Do not touch the batteries directly with your hands when removing them. They may be hot or battery fluid may be leaking from them.

4. Consult with the dealer where you purchased the keyboard or with an authorized service provider.

■ Be careful of the bags around children.

*. Never allow anyone to place the plastic bags of the instrument, its accessories, and its separately sold options over their heads. Doing so may cause suffocation. Particular caution is required in homes with small children.

! CAUTION

■ AC Adapter

 *. Do not locate the power cord in close proximity to heaters or other heating appliances. This may cause the cord to melt leading to possible fire or electrical shock.

 *. When unplugging the AC adapter from an electrical outlet, always make sure to pull on the adaptor itself and not the cord. Pulling excessively on the cord may cause it to be damaged or break leading to possible fire or electrical shock.

 *. Do not touch the AC adapter with wet hands when it is plugged in. This may cause electrical shock.

*. When not using the instrument for an extended period such as when travelling, always make sure to unplug the AC adapter from the electrical outlet for safety reasons.

*. After use turn off the power switch of the instrument and unplug the AC adapter from the electrical outlet.

■ Batteries

*. Improper battery use may cause batteries to rupture and leak. This may cause injury, malfunction of the instrument or discolouration of furniture and other articles that come into contact with battery fluid. Take care to observe the followings.

*. Install batteries so their polarity (+/-) matches that indicated on the instrument.

*. For safety and to prevent possible leakage of battery fluid, always make sure to

■ remove batteries from the instrument when you do not plan to use it for a long time.

*. Always make sure that the batteries making up a set are all of the same type.

*. Never combine the new batteries with old ones.

*. Never dispose of batteries by incinerating them. Never short or disassemble batteries, and do not expose them to excessive heat.

*. Replace dead batteries as soon as possible.

*. Never attempt to recharge batteries.

■ Transport

 *. When transporting the instrument, always make sure to unplug the AC adaptor from the electrical outlet and confirm that all other external connections have been disconnected. Only then should the instrument be transported. If the above is not done, the cord may be damaged leading to possible fire or electrical shock.

■ Care

 *. Whenever caring, make sure to first unplug the ac adaptor from the electrical outlet. Also remove the instrument's batteries if battery power is being used.

■ Location

 *. Never locate the instrument in areas subject to high humidity or heavy accumulation of dust. Doing so may cause fire or electrical shock.

*. Never locate the instrument in areas subject to grease splatters or steam, such as in a kitchen or near a humidifier. Doing so may cause fire or electric shock.

■ Don not place keyboard on lacquered furniture.

*. The instrument's silicone rubber feet may eventually blacken or scar lacquered surfaces. Use felt cloth pads to insulate the feet preferably use a musical instrument stand designed for your keyboard.

■ Do not place heavy objects on the instruments.

*. Do not place heavy instruments on the instruments. This may cause the instrument to tip over or break resulting in injury.

■ Volume

*. Very high volume levels can damage hearing. Avoid using the instrument at very high volume settings for long periods. Consult with a physician immediately if you experience impaired hearing or ringing in the ears.

■ Liquid Crystal Display (LCD) Precautions

*. Avoid subjecting the keyboard's LCD to strong impact, which can crack or break the LCD's glass creating the danger of personal injury.

*. Should the LCD glass ever crack or break, do not allow the liquid inside the LCD to come into contact with your skin, which can cause inflammation and reddening.

*. Should the LCD liquid get into your mouth, immediately wash out your mouth with water and then consult a physician.

*. Should the LCD liquid get into your eyes or on your skin, immediately flush with water for at least 15 minutes and then consult a physician.


■ Do not get onto the instrument or stand.*

*. Do not crawl on top of the instrument or its optional stand. Particular caution is required in homes having small children. This may cause the instrument or stand to tip over and break resulting injury.

■ Optional stand*

*. Carefully assemble the stand following the assembly instructions that come with it. Securely tighten all bolts, nuts, and fasteners, and make sure that you mount the instrument correctly onto the stand. Incorrectly or insufficiently tightening screws, or incorrectly mounting the instrument onto the stand can cause the stand to tip over or the instrument to fall off the stand, possibly leading to injury.

* The stand is available as an option.

**1.Power switch (STAND BY / ON)**

This turns the Touch function on and off.

2.[MASTER VOLUME] dial

(See P.12)

This determines the overall volume of the W8808A.

3.[VOICE] buttons

These are used to select the various voices of the W8808A. (See P.10)

4.[DUAL]button

It is to turn on / off the Dual voice. (See P. 11)

5.[SUSTAIN] button

This turns on / off the Sustain function. (See. P. 12)

6.[REVERB] button

It is to turn on / off the reverberation. (See P.12)

7.[TOUCH] button**8. [CHORUS] button**

It is to turn on / off the Chorus function.

(See P.12)

9.[HARMONY] button

This turns on / off the Harmony function.

(See P.13)

10.[Minus Channel] button

It is to control the Channel of the keyboard.

(See P.13)

11.[PERCUSSION] button

This turns on / off the percussion. (See P.23)

12.[SEARCH] dial

This is to search the function of [+ / -] button. (See P.11)

13.[DEMO] button

This turn on / off the demonstration function. (See P.10)

14. [ACMP VOLUME] button

It is to control the volume of the accompaniment. (See P.14)

15.[TEMPO] button

It is to control the tempo of the accompaniment and the demonstration songs. (See P.14)

16.[STYLE] button

It is to decide the accompaniment style of W8808A. (See P.14)

17.[FUNCTION] button

It is to select the function pattern. (Each press comes with a different function pattern). (See P.11)

18.[+ / YES] & [- / NO]

19. [ACMP ON/OFF] button

When the accompaniment mode is selected, this turns the auto accompaniment on and off. In the Song mode, this calls up the A-B Repeat function. (See P. 15, 29)

20.[SYNC STOP] button

It is to turn on / off the SYNC Stop function. (See P. 19)

21.[SYNC START] / [PAUSE] button

It is to turn on / off the SYNC Start function in accompaniment mode; and it temporarily pauses the song playback in Song mode. (See P.16, 29)

22.[START/STOP] button

It is to start / stop the auto accompaniment in Style mode; and to start / stop song playback in Song mode. (P.15)

23.[INTRO] button

It is to control the Intro function in Style mode; and when the Song mode is selected, this is used as a “rewind”

Control, or moves the song playback point back toward the beginning. (See P.16)

24.[MAIN A] button

It is to control the auto fill and change the auto accompaniment sections while in Style mode; and fast rewind the song or move the song playback point back toward the beginning in Song mode. (See P.20)

25.[MAIN B] button

It is to control the auto fill and change the auto accompaniment sections while in Style mode; and when Song mode is selected, this is used as a “fast forward” control, or move the song playback point toward the end. (See P. 20)

26. [ENDING] button

This button controls the ending function in the Style mode, and when Song mode is selected, this is used as a “fast rewind” control, or moves the song

Playback point back toward the beginning . (See P. 18)

27.[REGISTRATION MEMORY] buttons

These buttons ([MEMORY], [REGISTER], [N1]-[N4]) are used for selecting and recording the Registration Memory presets. (See P.33)

28.[SONG RECORDING] buttons

These buttons ([RECORD], [BANK], [M1]-[M5], [A]) are used for recording the songs. Each song can be recorded with at most six musical tracks (including a special chord track). (See P.25)

29.[METRONOME]

Information about this function please refer to P. 23.

30.[STYLE FREEZE] button



This is to recall the freeze accompaniment parameters in the Style Mode. (See P. 10)

31.PITCH BEND ROLLER

It is to simulate the pitch bend of the natural musical instruments. (See P.12)

External Terminals


REAR PANEL



BACK BOARD

BACK BOARD


FOOT SWITCH



- 20 Headphone / Auxiliary Output P. 9
- 21 AC Adapter Socket P. 9
- 22 Rear Panel P. 9
- 23 MIDI IN P. 9, 35
- 24 MIDI OUT P. 9, 35
- 25 Footswitch P. 9
- 26 Sustain Pedal P. 12
- 27 Sostenuto Pedal P. 12
- 28 Soft Pedal P. 12


PREPARATIONS

■ Setting Up



1. Fix the left and right feet on the ground board with 4 black screws at each side.
2. Put 8 wooden screws into the small holes in the front left and right feet. 4 for each side. Then fix these feet separately on the ground board and ground feet.
3. Place the piano body onto the plank, and fix it with 4 zinc-gilded screws at each side as shown in the illustration.
4. Connect the cable of foot switch with the socket cable (As shown in the illustration).
5. Move the screw between the sustain pedal and damper pedal right onto the ground, in order to pin up the pedal.
6. Use 6 screws to fix the baffle on the angle iron corresponding to the pedal and left & right back feet.

■ Using Headphones or Stereo System



You can connect a set of stereo headphones to the PHONES/OUTPUT jack. While such connection is made, you could only hear the sound through the earphone. Thus, you could practice and play without disturbing others. This jack can also be connected to the external amplifier / speaker system, in order to form a better amplifier system.

■ MIDI INPUT / OUTPUT



MIDI IN could be used to receive the MIDI data from the outside equipment connected.


MIDI OUT could send the MIDI Data of this instrument.

PLAYING THE PIANO

STARTING TO PLAY THE PIANO

■ TURNING ON THE INSTRUMENT


Before plugging in the AC cable, set the [POWER] to “0”. First plug the power cable output in [AC Socket], then connect the cable input with the 220V alternating current. Press down the “1” on the POWER switch, then the LCD displays.



POWER

SETTING THE VOLUME

Set the [MASTER VOLUME] dial to a suitable place, about 1/4 circle. Also you can adjust it after playing.



VOLUME

DEMO SONGS

There are all together 22 demonstration songs in this instrument, which thoroughly display its excellent quality in the tone and melody. You can get a general idea of this instrument through them.

■ Playing all demo songs

Press the [DEMO] button, and all the demonstration songs would be performed in order.

■ Playing a single selected demo song

After pressing the [DEMO] button, you could use [+ / YES] and [- / NO] to select the appropriate number of the desired song during playback, also you can use the [SEARCH] dial to select the number.

Voice

In this instrument, there are 348 vivid voices, including 25 Chinese voices, and many GM voices. All these are separated into A and B groups and all leading voices are printed on the panel. At the upper part of each voice button are voices of Group A and lower part of Group B.

■ Selecting a Voice

- ① Press [MAIN A / B] to select a voice.
- ② Press the [VOICE] button to choose a leading voice
- ③ Press [+ / YES] and [- / NO] or use the [SEARCH] dial to decide the voice you desire.

NOTE:

You should wait 2 or 3 seconds if you want to restart the instrument. The time is to let the internal circuit discharge thoroughly. Otherwise, the performance will go abnormal to a certain extent.

NOTE:

Usually, you should set the [MASTER VOLUME] dial within 3 / 4 circle. Otherwise, certain note may not be properly voiced.

NOTE:

You can still play on the keyboard while the demo song is being played, but if the sound overpasses the maximum value, it might not be voiced.

NOTE:

Only the names of leading voices are printed on the panel. In fact each voice has its variations. While selecting a voice, you can see the name in the LCD.

Dual Voice

This function allows you to play two voices at the same time.

- ① Follow the previous Selecting a Voice process to choose the first voice.
- ② Press the [DUAL] button to enter into Dual Voice mode. The name of the second voice will appear in the LCD;
- ③ Follow the previous Selecting a Voice process again to choose the second voice;
- ④ Press the [DUAL] button to stop Dual Voice function.

NOTE:

- In Dual Voice mode, if you press the keyboard, it may sound differently or like two voices mixed together. If you press this button right after you turn on this instrument, stringed instruments ensemble 1 would be automatically set as defaulted second voice.
- In this mode, you cannot choose the first voice, so you ought to settle the first voice before entering into this mode.

■ Balancing the Dual Voice

You should balance the volume of each voice by yourself.

- ① Press the [FUNCTION] button until it shows “ Second Voice Volume ” in the LCD.
- ② Press [+ / YES] and [- / NO] or use the [SEARCH] dial to adjust the second voice volume, ranging from 0 to 127.

NOTE:

By pressing [+ / YES] and [- / NO] at the same time, the volume would return to the primary setting.

CONTROL AND EFFECT

This digital piano offers you various types of effects. You can freely choose your favourite one.

The Usage of Function buttons

- Press each button once to choose different function
 - 1.Voice 2. Style mode 3.Demo Song 4 Minus Channel (for demon songs) 5. Harmony 6. Chorus 7. Transpose 8.Tuning 9. Dual Balance 10. Metronome
- Stop certain function or return to the primary setting by pressing [+ / YES] and [- / NO] at the same time.

Withdraw from the Function MENU.

- Press the [FUNCTION] button for 2 seconds to withdraw from the Function MENU.


Using the [SEARCH] dial

- Adjust the [SEARCH] dial to select certain function directly.
- Any function that can be controlled by the [+ / YES] and [- / NO] can be applied to this dial.
- Adjust the [SEARCH] dial.

FUNCTION



SEARCH



■ Pitchbend Roller

It is used to adjust the voice volume when playing this instrument, simulating the pitch bend of natural musical instruments. This enables certain voices (e.g. guitar) to be more vivid, and display different music styles.

Using Pitch bend Roller

Turn the roller with your left hand while your right hand is playing on the keyboard.

■ Footswitch

- ① Using the Sustain Pedal can add sustain effect to the melody.
- ② The Sostenuto pedal is used to sustain one note or one chord and meanwhile having no effect on other notes.
- ③ You can diminish the melody pitch by using Soft Pedal.

■ Touch Response

This function could adjust the volume by controlling the strength of pressing the keyboard.

There are five touch types (Touch SNS 15) available by pressing the [TOUCH] button in the panel.

- ① Press the [TOUCH] button to enable this function, and the Touch icon appears in the LCD.
- ② Press the [TOUCH] button for at least 3 seconds, and the name of the type appears in the LCD.
- ③ You can change the touch type by using [+ / YES] and [- / NO] buttons or [SEARCH] dial.

■ Reverb

This function is to add reverberation effect to the voices, which can create live effect and sound as if you were performing in a small room or a concert. A total of eight different Reverb types simulating various different performance environments are available. Press the [REVERB] button to shift this mode.

- ① Press the [REVERB] button for at least 3 seconds to enable this function, and there appears the Reverb icon in the LCD.
- ② You can change the reverberation type by using [+ / YES] and [- / NO] buttons or [SEARCH] dial.


■ Chorus

It is to add chorus effect to the voices. There are 8 different types available.

- ① Press the [FUNCTION] button to choose this function, and the Chorus icon appears in the LCD.
- ② You can close this function and change the chord type by using [+ / YES] and [- / NO] buttons or [SEARCH] dial.

NOTE:

- This Roller has no effect on Auto Bass chord.
- The primary setting is +/- 200 dieresis (2 semitones), and the adjust range is +/-1 octachord.



NOTE:

The keyboard will automatically call up touch response after you turn it on. Its default touch type is medium response. As to setting the parameter in touch function, please see P.63.

NOTE:

More information please see P. 43. This instrument will automatically call up Reverberation On mode after you turn it on.

NOTE:

• By pressing [+ / YES] and [- / NO] at the same time, the tuning would return to its primary setting.

More information please see P. 43.

■ Tuning

This function determines the fine pitch setting of both the main voice and the bass/chord accompaniment of the selected style. It also determines the pitch of the songs. This allows you to accurately match the tuning with that of other instruments without changing your fingering. The Tuning setting can be adjusted over a range of +/- 100 (approx. +/- 1 semitone).

- ① Press the [FUNCTION] button to select this function, and the Tune icon appears in the LCD.
- ② You can change the tuning by using [+ / YES] and [- / NO] buttons or [SEARCH] dial.

NOTE:

By pressing [+ / YES] and [- / NO] at the same time, the pitch would return to the primary setting.

More information please see P. 43.

■ Transpose

This function determines the key of both the main voice and the bass/chord accompaniment of the selected style. It also determines the pitch of the songs. This allows you to easily match the pitch of this instrument to other instruments or singers, or play in a different key without changing your fingering. The transpose settings can be adjusted over a range of +/-12 semitones (+/-1 octave).

- ① Press the [FUNCTION] button to select this function, and the Transpose icon appears in the LCD.
- ② You can adjust the range of transpose by using [+ / YES] and [- / NO] buttons or [SEARCH] dial.

NOTE:

- By pressing [+ / YES] and [- / NO] at the same time, the mode would return to the primary setting. A new mode is only valid to the notes played after this new mode is set.
 - This function is to change the places of the notes, in order to display the melody and accompaniment for the present voice and accompaniment style. But it has no effect on keyboard percussion music.
 - Please refer to P.43 for the details of setting the transpose parameters.
-

■ Harmony

The Harmony section features a variety of performance effects that enhance the melodies you play when using the accompaniment styles of the W8808A. A total of twenty-six Harmony types are available.

Tremolo, Trill and Echo effects can be used even if accompaniment is off. There are five different Harmony Types that automatically create harmony parts (for notes played in the upper section of the keyboard) to match the accompaniment chords.

- ① Press the [FUNCTION] button to select this function. When “Harmony Disabled” appears in the LCD, it means this function is closed.
- ② Press [+ / Yes] to enter into harmony mode.
- ③ You can choose your desired harmony type by using [+ / YES] and [- / NO] buttons or [SEARCH] dial.

NOTE:

- For the first ten Harmony Types (Duet, Octave, Tremolo 1/4, Tremolo 1/6, Tremolo 1/8, Tremolo 1/12, Echo 1/4, Echo 1/6, Echo 1/8, Echo 1/12), chords must be played in the Accompaniment section of the keyboard.
 - The harmony voice will change its pitch to match the chord you are playing.
 - The speed of the Tremolo, Trill and Echo effects depends on the Tempo setting.
 - Each voice of the W8808A has its own independent Harmony setting.
-

■ Minus Channel

This function controls the keyboard channel and has effect only on the demo songs, which makes easier for users to practise to the demo songs.

- ① While playing the demo songs, pressing [MINUS CHANNEL] button can turn on / off the keyboard channel of the demo song.
- ② Pressing [MINUS CHANNEL] button at least 3 seconds to close the channel you desired.
- ③ Use [+ / YES] and [- / NO] or adjusting [SEARCH] dial to select left channel or right channel.

ACCOMPANIMENT STYLE

W8808A provides dynamic rhymes and accompaniment patterns, as well as voice settings appropriate for each pattern for various popular music styles.

A total of 100 kinds of different accompaniment styles are available, in two different categories Group A and Group B. All leading styles are printed on the panel. At the upper part of each style button are styles of Group A and lower part Group B. Each style is made up of separate “sections” : Intro, Main A / Auto Fill-in, Main B / Auto Fill-in and Ending, letting you call up accompaniment sections as you perform. The auto accompaniment features that are built into the rhythms add the excitement of instrumental backing to your performance, letting you control the accompaniment by the chords you play. Auto accompaniment effectively splits the keyboard into two sections: the upper is used for playing a melody line, and the lower (set by default to keys F#2 and lower) is for the auto accompaniment function.

Selecting a Style

- ① Press Group A / B button to choose the group you prefer. When the LED light is on, it means Group B is selected; if off, it means Group A.
- ② By pressing [STYLE] button, you can choose the leading pattern in each accompaniment style.
- ③ You can change the rhythm by using [+ / YES] and [- / NO] buttons or adjusting the [SEARCH] dial.

NOTE:

- The accompaniment styles printed on the panel are the leading patterns in each style. Each style actually concludes one or several different patterns.
- The name of the accompaniment style you choose will be shown in the LCD.

Variation

Each accompaniment style has its own variations. There are Variation A/B button on the panel.

Adjusting the Accompaniment Volume

Use the [▲] [▼] volume buttons to adjust the accompaniment volume. The range of this adjustment is from 0 to 127.

ACMP VOLUME



Adjusting the Accompaniment Tempo

Use the [▲] [▼] tempo buttons to adjust the accompaniment tempo, and its range is from 40 to 240.

TEMPO



NOTE:


By pressing [▲] [▼] buttons at the same time, the volume will return to its primary setting.

NOTE:

By pressing [▲] [▼] buttons at the same time, the tempo will return to its primary setting.


■ Playing the Accompaniment

The panel buttons below function as accompaniment controls.



1 Turn on the auto accompaniment

Press the [CHORD] button to enable (turn on) the auto accompaniment.




2 Start the accompaniment

You can do this in one of the following ways:


Press the [START / STOP] button

The rhythm starts playing immediately without bass and chord accompaniment.

The currently selected Main A / B section will play.




You can select the Main A / B section by pressing the appropriate button [MAIN A/B] before pressing the [START / STOP] button. (The display briefly shows the letter of the selected section: "MAIN A" or "MAIN B" .)



Sync Start

W8808A has Sync Start function that allows you to start the accompaniment and rhythm by simply pressing a key on the keyboard. To enable this function, first press the [SYNC START] button, (the beat marks all flash to indicate Sync Start stand-by), then press any key / chord on the keyboard. (When auto accompaniment is on, play a key or chord in the auto accompaniment section of the keyboard.)




Starting with an Intro section.


Each style has two or four-measure Intro sections. When used with auto accompaniment, many of the Intro sections also include special chord changes and embellishment to enhance your performance.

To Start with an Intro section.

- 1). Press [MAIN] button to select which section (A or B) is to follow the Intro.



- 2) Press [INTRO] button.




To actually start the Intro section and accompaniment, press the [START / STOP] button.
Using Sync Start with an Intro section


You can also use the Sync Start function with the special Intro section of the selected style.

To use Sync Start with an Intro section:



- 1). Press [MAIN] to choose which section (A / B) is to follow the Intro.



- 2) Press [INTRO] button.



- 3). First press the [SYNC START] button to enable this function, and then start the Intro section and accompaniment by playing any key on the keyboard. (When auto accompaniment is on, play a key or chord in the auto accompaniment section of the keyboard.)



1. Using the Auto accompaniment function to change chords


Try playing a few successive chords with your left hand, and experience how the bass and chord accompaniments change with each chord you play.

2. Stop the accompaniment

There are three ways to stop the accompaniment.

■ Pressing the [START / STOP] button

The rhythm and accompaniment stops playing immediately.




NOTE:

Chords played in the auto accompaniment section of the keyboard are also detected and played when the accompaniment is stopped. In fact, this gives you a "split keyboard," with bass and chords in the left hand and the normally selected voice in the right.


■ Using an Ending section

Press the [ENDING] button, then the accompaniment stops after the Ending section is finished.



■ Pressing the [SYNC START] button


Doing this can immediately stop the accompaniment and automatically enables Sync Start, letting you re-start the accompaniment by simply playing a key or a chord in the auto accompaniment section of the keyboard.



Changing the Split Point of the Accompaniment Track

Press the [ACMP SPLIT] button until in the LCD appears “ Select the Accompaniment Track Split Point” .


Then use [+ / YES] and [- / NO] buttons or [SEARCH] dial to change the split point you want.



Changing the Keyboard Split Point

Press the [CHORD] button until in the LCD appears “ Split” .

Then use [+ / YES] and [- / NO] buttons or [SEARCH] dial to change the keyboard split point you want.




SYNC Stop

This convenient feature lets you stop / pause the auto accompaniment by releasing your fingers from the auto accompaniment section of the keyboard. Playing the chord again restarts the auto accompaniment. This is ideal for putting dynamic breaks in your performance for example, stopping the rhythm and accompaniment briefly while you play a melodic break or solo with your right hand.


1 Press the [ACMP] button.

To enable the accompaniment function. By pressing [CHORD] button repeatedly, you can get KEYBOARD SPLIT, SINGLE FINGER CHORD, FINGERED CHORD, CHORD CLOSE, ACCOMPANIMENT functions in order.




2 Press the [SYNC STOP] button.

Setting Sync Stop to on before starting the auto accompaniment automatically sets Sync Start on as well.



3 Play a chord on the keyboard (in the auto accompaniment section of the keyboard). The auto accompaniment starts automatically as soon as you play a chord.

4 Stop the auto accompaniment by releasing the chord.



5 To start the auto accompaniment again, just play a chord.




6 To turn Sync Stop off, please press [SYNC STOP] button once more. Pressing [START / STOP] button can completely stop the auto accompaniment.

Accompaniment Sections (Main A / B and Fill-ins)

While the accompaniment is playing, you can add variation in the rhythm / accompaniment by pressing the [MAIN / AUTO FULL] button. This switches between the Main A and Main B sections, automatically playing a fill-in pattern to smoothly lead into the next section. For example, if the Main A section is currently playing, pressing this button automatically plays a fill-in pattern, followed by the Main B section. (See illustration on this page) If you do not want to change to the Main B after a fill-in is being played, just press [MAIN A] right after pressing [MAIN B], then you can enjoy Main A again.

You can also select either the Main A or B section to start by pressing the [MAIN / AUTO FILL] button before starting the style.




About the Fill-in Patterns

If you press the [MAIN / AUTO FILL] button before beat 4...

...A fill-in pattern plays immediately until the end of the measure...

And the Main A / B section plays here.






Using Auto Accompaniment—Multi Fingering

When it is set to on, the auto accompaniment function automatically generates bass and chord accompaniment for you to play along with, by using Multi Fingering operation. You can change the chords of the accompaniment by playing keys in the auto accompaniment section of the keyboard using either the “Single Finger” or “Fingered” method. With Single Finger you can simply play a one-, two- or three-finger chord indication (see Single Finger Chords below). The Fingered technique is that of conventionally playing all the notes of the chord. Whichever method you use, the W8808A understands what chord you indicate and then automatically generates the accompaniment.










■ Single Finger Chords.

Chords that can be produced in Single Finger operation are major, minor, seventh and minor seventh. The illustration below shows how to produce the four chord types. (The key of C is used here as an example; other keys follow the same rules. For example, B \flat 7 is played as B \flat and A.)

			
<p>To play a major chord: press the rootnote of the chord.</p>	<p>To play a minor chord: press the rootnote together with the nearest black key to the left of it.</p>	<p>To play a seventh chord: press the rootkey together with the nearest white key to the left of it.</p>	<p>To play a minor seventh chord: press the rootkey together with the nearest white and black keys. (three keys together)</p>

Fingered Chords.

Using the key of C as an example, the chart below shows the types of chords that can be recognized in the Fingered mode.

Example for C chords									
C	C ⁽⁹⁾	C ₆	C ₆ ⁽⁹⁾	CM ₇	CM ₇ ⁽⁹⁾	CM ₇ ^(#11)	C ^(b5)	CM ₇ ^{b5}	
									
C _{sus 4}	C _{aug}	CM ₇ _{aug}	Cm	Cm ⁽⁹⁾	Cm ₆	Cm ₇	Cm ₇ ⁽⁹⁾	Cm ₇ ⁽¹¹⁾	
									
CmM ₇	CmM ₇ ⁽⁹⁾	CM ₇ ^{b5}	CmM ₇ ^{b5}	Cdim	Cdim ₇	C ₇	C ₇ ^(b9)	C ₇ ^(b13)	
									
C ₇ ⁽⁹⁾	C ₇ ^(#11)	C ₇ ⁽¹³⁾	C ₇ ^(#9)	C ₇ ^{b5}	C ₇ _{aug}	C ₇ _{sus 4}	C ₁₊₂₊₅		
									

*Notes enclosed in parenthesis are optional; The chords will be recognized without them.

Chord Name (abr.)	Common Voicing	Chord (C)	Display
Major[M]	1-3-5	C	C
Add ninth[(9)]	1-2-3-5	C(9)	C(9)
Sixth[6]	1-(3)-5-6	C6	C6
Sixth add ninth[6(9)]	1-2-3-(5)-6	C6(9)	C6(9)
Major seventh[M7]	1-3(5)-7or1-(3)-5-7	CM7	CM7
Major seventh ninth[M7(9)]	1-2-3(5)-7	CM9(9)	CM9(9)
Major seventh sharp add eleventh[M7(#11)]	1-(2)-3-#4-5-7or 1-2-3-#4-(5)-7	CM7(#11)	CM7(#11)
Flatted fifth[(b5)]	1-3-b5	C(b5)	C(b5)
Major seventh flatted fifth[M7aug]	1-3-b5-7	CM7b5	CM7b5
Suspended fourth[sus4]	1-4-5	Csus4	Csus4
Augmented[aug]	1-3-#5	Caug	Caug
Major seventh augmented[M7aug]	1-(3)-#5-7	CM7aug	CM7aug
Minor[m]	1-b3-5	Cm	Cm
Minor add ninth[m(9)]	1-2-b3-5	Cm(9)	Cm(9)
Minor sixth[m(6)]	1-b3-5-6	Cm6	Cm6
Minor seventh[m(7)]	1-b3-(5)-b7	Cm7	Cm7
Minor seventh add ninth [m7(9)]	1-2-b3-(5)-b7	Cm7(9)	Cm7(9)
Minor seventh add eleventh[m7(11)]	1-(2)-b-3-4-5-(b7)	Cm7(11)	Cm7(11)
Minor major seventh[mM7]	1-b3-(5)-7	CmM7	CmM7
Minor major seventh ninth[mM7(9)]	1-2-b3-(5)-7	CmM7(9)	CmM7(9)
Minor seventh flatted fifth[m7b5]	1-b3-b5-b7	Cm7b5	Cm7b5
Minor major flatted fifth[mM7b5]	1-b3-b5-7	CmM7b5	CmM7b5
Diminshed [dim]	1-b3-b5	Cdim	Cdim
Diminshed seventh[dim7]	1-b3-b5-6	Cdim7	Cdim7
seventh [7]	1-3-(1)-b7 m 1-(3)-5-b7	C7	C7
seventh flatted ninth[7(b9)]	1-b2-3-(5)-b7	C7(b9)	C7(b9)
Seventh add flatted thirteenth[7(b13)]	1-3-5-b6-b7	C7(b13)	C7(b13)
Seventh ninth[7(9)]	1-2-3-(5)-b7	C7(9)	C7(9)
Seventh add sharp eleventh[7(#11)]	1-(2)-3#4-5-b7or 1-2-3-#4-(5)-b7	C7#(11)	C7#(11)
Seventh add thirtesnth[7(13)]	1-3-(5)-6-b7	C7(13)	C7(13)
Seventh sharp ninth[7(#9)]	1-#2-3-(5)-b7	C7(#9)	C7(#9)
Seventh flatted fifth[7b5]	1-3-b5-b7	C7b5	C7b5
Seventh augmented[7aug]	1-3-#5-b7	C7aug	C7aug
Seventh suspended[7sus4]	1-4-(5)-b7	C7sus4	C7sus4
One plus two plus five[1+2+5]	1-2-5	C1+2+5	C

NOTE:


- Notes in parentheses can be omitted.
- Playing two same root keys in the adjacent octaves produces accompaniment based only on the root.
- A perfect fifth (1+5) produces accompaniment based only on the root and fifth which can be used with both major and minor chords.
- The chord fingerings listed are all in “root” position, but other inversions can be used with the following exceptions: m7, m7 b 5, 6, m6, sus4, aug, dim7, 7 b 5, 6(9), 1+2+5.
- Inversion of the 7sus4 and m7(11) chords are not recognized if the notes shown in parentheses are omitted.
- The auto accompaniment will sometimes not change when related chords are played in sequence (e.g. some minor chords followed by the minor seventh).
- Two-note fingerings will produce a chord based on the previously played chord.

PERCUSSION

KEYBOARD PERCUSSION

By applying percussion function, you can give a vivid performance as if you were playing a drum or some other percussion instruments. This keyboard can produce 61 different kinds of percussion music, and 18 traditional Chinese percussions.

- ① Press [PERCUSSION] button to select the percussion.



- ② Press [PERCUSSION] button at least 3 second, then you can see keyboard percussion groups in the LCD.
- ③ Then use [+ / YES] and [- / NO] buttons or [SEARCH] dial to select the keyboard percussion group you desired.
- ④ By playing on the keyboard you can get the percussion music you want. On each key there is a certain icon standing for a corresponding percussion. By this key, you can get the music vivid to this real percussion. All the percussion and keys are list in Page 41.
- ⑤ By pressing [PERCUSSION] button or any other voice button you can close this percussion function.

NOTE:

- When the Percussion function is on, you cannot change the present melody. Moreover, if you choose a certain voice after the percussion function is on, this function will be automatically cancelled.
- When the auto undertone function is on, the 19 lowest undertone keys (C1 to F2) cannot be applied to percussion music.


■ METRONOME

When the Metronome is on, it will voice in Song Playback / User Song Record mode.

- ① Press the [METRONOME] button to turn on/off this function.
- ② When the Metronome is on, press [SYNC START] button to enable it to voice.


NOTE

- The Metromome function is off when the power is just turned on.



SAVING SONGS


To save songs is to save your own performance (5 melody channels) and the accompaniment (chord channel) together as a song, in case sometimes you want to repeat it again. This instrument can save at most 5 songs. Saving Songs consists of 8 control buttons: [SONG NO.] to choose the song, [SAVE] to do the preparation, [MELODY 1-5] to choose the melody voice part, [CHORD / CLEAR] to select the chord and musical track and as well as clear the saved songs.



As a matter of fact, this function provides with 5 musical tracks available for saving the melody (Melodies in each track can choose different kinds of voices and percussions) and one special channel to save the accompaniment (using Style mode or auto bass chord function). Please save the songs with the methods below:

Save any melody track or chord track. (Single track record)

When the auto bass chord function is on, save the melody track and chord track together. (Double tracks record)



NOTE:

There's no special difference between single-track recording and double-track recording. Even when you record the melody and chord performance by double-track recording, this instrument can automatically separate it into melody track and chord track according to your performance. Thus, you can re-record a certain track (or correct an error) after double-track recording.

In addition, each track can save what stated below

Melody1-5: the melody played on the keyboard, voice, dual on/off (and the choice of the second voice), dual balance, reverb on/off, sustain on/off, pitch bend roller, touch response on/off, percussion, chord on/off (with the parameters you've set), transpose on/off (with the parameters you've set).


Chord: the chord played on the keyboard (regardless of auto bass chord mode), Style choice, accompaniment proceeding (intro, fill-in, ending, A/B variation on/off, change of accompaniment volume).

NOTE:

Both the beginning tempo and the tempo change in the recording will be recorded as parts of the song.

SONG RECORDING

W8808A features powerful and easy-to-use song recording features that let you record your keyboard performances using up to six independent tracks (including one track for accompaniment) for creating your own complete, full orchestrated compositions. You can record and save up to five User songs.



Song recording on the W8808A is similar to using a tape recorder; whatever you play on the keyboard is recorded in real time as you play it. Also, when you record subsequent parts to other tracks, you can hear the previously recorded parts as you record new ones.

Recording a User Song

The data that can be recorded to normal (melody) tracks are listed as below:

Note on/off	Velocity *
Touch Type	Sustain
Voice Number	Tempo, Time Signature (if it is not in the chord track)
Reverb Type	
Chorus Type *	

The data recorded into Chord track:

Style number *	Accompaniment Volume *
Chord changes and timing	Tempo, Time Signature
Changing Sections (Intro, Main A/ B, Fill-in, Ending, etc.)	

* Those settings can be recorded only once when the music begins, while others can be changed during the music.


1 To make all desired W8808A settings.

Before you actually start recording, you'll need to make various settings for the songs such as selecting a style, setting the Tempo, and selecting a voice.

If desired, also make other settings. Refer to the list above for settings that can be recorded to a song.

2 To select a User song number for recording.

Press [SONG NO] button, and use [+ / Yes] or [- / No] button to choose song number you want for recording.




3 To chose the recorded track number.

While holding down the [RECORD] button, press the appropriate Song Memory button. Melody track 1 to 5 can only be chosen once at a time and the display light of time signature flicks. The track number temporarily appears in the LCD before it recovers to its the previous display.


NOTE:

Keep in mind that all recording operations replace all the information recorded before. In other words, if you record to a track that already has recorded data; all previous data in the track will be erased and replaced by the newly recorded data.



Recording to the Chord Track

A special chord track is prepared for recording accompaniment data. This is automatically recorded to the Chord track (track A). Selecting the chord track will also automatically turns on the accompaniment.



Recording to a Melody Track (1 to 5)

Five independent melody tracks are prepared to record your keyboard performance. Usually, you'll want to record these after you've recorded the Chord track. But you can also simultaneously record Chord track and one Melody track.

Muting Tracks During Playback

While the recording is enabled, you can selectively mute different tracks. This is useful for when you want to clearly hear certain tracks, and not others, during recording. Muting can also be done “on the fly” during playback. To use muting, press the corresponding SONG MEMORY button, repeatedly if necessary, until the desired track number in the display is off.

Each press of a SONG MEMORY button (when playback is stopped) cycles through the following settings.

4 To start recording.

When the beat marks and track number start flashing, you can start recording simply by playing the keyboard (or by pressing the [START/STOP] button).

When Sync start is on, play the first chord of the song in the auto accompaniment section of the keyboard. The accompaniment starts automatically and you can continue recording, playing other chords in time with the accompaniment.

NOTE:

If the previous accompaniment track or melody track is on, it can be monitored during the recording. If no of that track is needed, you can press its button again to close it. The screen will show the current track number in the “state” column.

5 Stop recording:

After you finished playing the song you want to record, press the [START/ STOP] button or [RECORD] button to stop recording.

6 Record to other tracks as desired.

To do this, simply repeat step 3 to 5 above. Make sure that when you press the [SONG MEMORY] button corresponding to the desired track, the track number in the display flashes.

7 Listen to newly recorded song:

To play back the song from the beginning, simply press the [START/STOP] button again. Playback stops when the [START/STOP] button is pressed again.

NOTE:


If no power is provided, the recorded data can only be reserved for one week or more. Important data should be stored in other equipment through the function of batch output.

SONG CLEAR

The Song Clear operation completely erases all the recorded data on all tracks of a selected User song. Use this operation only when you are sure you want to erase a song and record a new one. To erase an individual track of a song while leaving the other tracks intact, use the Track Clear operation.


1 Select the desired song.

Press the [SONG NO] button, and then use [+ / YES] or [- / NO] button to select the desired song (between No.1 to No.5).



2 While holding down the [RECORD] button, press Song Memory buttons.

All track indications in the LCD flash, indicating that all tracks are to be erased.



3 Press [+ / YES] button.

4 At the “Sure?” prompt, press the [+ / yes] button, or press the [- / NO] button to abort.

Press the [+ / YES] button is to clear the desired song. LCD shows “Sure?”

Again press the [+ / YES] button and LCD says, “Cleared” .


Press button [- / NO] is to cancel the operation.

TRACKS CLEAR

The Track Clear operation is to completely erase all the recorded data on a selected track of a selected User song, leaving the other tracks intact. Use this operation only when you are sure to clear a track and record a new one. To erase the data of an entire song, use the Song Clear operation.


1 Select the desired song.

Press the [SONG NO] button, and then use the numeric keypad or press [+ / Yes] or [- / No] button to select the desired song (No.1 to No.5).



2 Press and hold down the button corresponding to the track to be erased.

Press and hold down the appropriate [SONG MEMORY] button ([M1]-[M5], [ACMP TRACK]) for at least one second.



3 Press the [+ / YES] button.

4 At the “Sure?” prompt, press the [+ / YES] button, or press the [- / NO] button to abort.


Pressing the [+ / YES] button is to clear the desired track. LCD shows “sure?”

Again press the [+ / YES] button and in the LCD says, “Cleared” .


Pressing button [- / NO] is to cancel the operation.

PLAYING A SONG


This button is the panel button of song control functions. Its usage covers your saved User songs and the demo songs.



About Song track:



- 1 Start the desired song.
Press [START / STOP] button.




- 2 Stop the song playback.
Press [START / STOP] button. If the playback is repeated by using the button [START/STOP], the song will automatically stop.

A—B REPEAT

This convenient A-B Repeat function is an ideal aid for practicing and learning. It allows you to specify a phrase of a song (from A point to B point), and repeat it while yourself practice or play along with it.


1 Set point A (the start point) while playing a song.

During the playback, press the [A-B REPEAT] button once, at the beginning point to be repeated.



2 Set point B (the end point).

While the song continues playing, press the [A-B repeat] button once again, at the place you want it to stop repeating. Thus, the selected phrase repeats indefinitely until stopped.




NOTE:

- The A and B points can only be specified at the beginning of a measure (beat 1), and not at any point in the middle of a measure.
- To set the A point to the beginning of a song, press the [A-B REPEAT] button before starting playback.


3 Pause or stop playback as needed.

Just use [PAUSE] or [START / STOP] button. Stopping playback does not cancel the set A / B point or the A-B Repeat function.



4 Turn off the A-B Repeat function


Press the [A-B REPEAT] button



HINT:

If you are repeat practicing a particularly difficult section, try slowing down the tempo to an appropriate speed to make it easier to play and master the part. You may also want to slow down the Tempo while setting the A / B point, this makes it easier to accurately set the points.

You can also set the A-B Repeat function while the song is paused or stopped. Simply use [F F] / [REW] button to select the measures you want, then press the [A-B REPEAT] button for each point, and finally just start playback.



REGISTRATION MEMORY


By applying this convenient function, you can save at most 32 panel settings (8 groups and 4 in each group). And you can recall any setting at any moment if you want.

Each panel consists of parameters below:


- Voice (as well as Group A / B choice);
- Dual Voice (Second voice choice and Dual balance)
- Chorus on/off, type
- Touch Type
- Reverb
- Transpose setting
- Style Number (as well as Group A / B choice)
- Tempo setting
- Tuning
- Harmony on / off and its type
- Accompaniment volume

RECORDING A REGISTRATION MEMORY PRESET

- 1 Press the [BANK] button then there appears “BANK” in the LCD. Using [+ / YES] and [- / NO] buttons to choose the group (18 groups)




- 2 Keep the [Registration Memory] button pressed and then press any button from N1 to N4. In LCD, there appears “Registration Memory” , and as well as the corresponding number. The new setting will be saved to corresponding place in the memory. The register number shows in the first line of the screen for a short time and then the original display recovers.




RECALLING A REGISTRATION MEMORY PRESET

1 First press [BANK] button, and then use [+ / YES] and [- / NO] to select the register number (from 1 to 18); if you do not select, it means to use the present memory bank.



2 Then press the register number you want, and it will be recalled. The register number will be shown in the first line of the screen for a short time and then the original display recovers.




NOTE.

- If no power is provided, the recorded data can only be reserved for one week or more. Important data should be stored in other equipment through the function of batch output.
- If do not select the memory bank first, then it will automatically use the present bank.

Accompaniment Lock function

This function can recall a registration number without changing the accompaniment parameters, which enables you to adopt different registration memory setting without interrupting the present accompaniment. Press [ACMP LOCK] button to turn on / off this function. When it is on, the LCD shows ACMP FREEZE ON.



NOTE

Selecting different Memory Bank will not close ACMP FREEZE function.

MIDI FUNCTIONS

W8808A is MIDI-compatible, featuring MIDI IN and MIDI OUT terminals and providing a variety of MIDI-related controls. By using MIDI functions, you can expand your musical possibilities. In this chapter, it mainly talks about what MIDI is, what it can do, and as well as how you apply MIDI to W8808A.

WHAT IS MIDI?


No doubt you have heard the terms---acoustic instruments and digital instruments. In the world today, these are the two main categories of musical instruments. Let's consider an acoustic piano and a classical guitar as representative acoustic instruments. They are easy to understand. With the piano, you strike a key, and a hammer inside hits some strings and plays a note. With guitars, you directly pluck a string and the note sounds. But how do digital instruments go about playing a note?

Acoustic guitar note production



Pluck a string and the body resonates the sound.

Digital instrument note production



Based on playing information from the keyboard, a sampling note stored in the tone generator is played through the speakers.

As shown in the pictures above, in digital instruments, the sample notes (reserved notes) stored in the tone generator section (electronic circuit) can be played when the information on the keyboard is collected. Then what is the information on the keyboard?

For instance, if you use W8808A to play a C quarter note, unlike an acoustic instrument that puts out a resonated note, it puts out information from the keyboard such as “with what voice” , “with which key” , “about how strong” , and “when was it pressed” and “when was it released” . All the information will be converted to a number value and sent to the tone generator. Based on these data, the music source will adopt stored sample note and play it.


MIDI FUNCTION

MIDI is the abbreviation of musical instruments digital interface. It allows the digital instruments to communicate with each other, by sending and receiving compatible notes, control change and program change, and as well as other types of MIDI data and information. MIDI is an international standard. It enables all the instruments to connect together, and allows them to control each other and exchange data. That is, it makes all the instruments a system, and greatly enlarges its function.

W8808A can control MIDI device by transmitting note-related data and various types of controller data, and also can be controlled by outside MIDI information, which can automatically decide the music source mode, and choose MIDI track, voice and effect, and change the parameter and as well as perform the appointed voice.

MIDI Interface

MIDI IN is to receive outside data from other MIDI devices like sequencer in order to control this instrument; MIDI OUT is to send MIDI data (like the note and touch data) from this instrument.



REMOTE PASSAGE

To set the MIDI passage to receive outside keyboard data, please select 01-16. The outside keyboard must set the source passage from which the data is sent and its MIDI OUT connects this keyboard's MIDI IN by the MIDI cable. When set is OFF, this keyboard will receive from all the 16 tracks. Pressing [-/NO] and [+ /YES] buttons at the same time can return to the original setting (OFF)

KEYBOARD OUTPUT

To determine whether the data output from the MIDI OUT.


NOTE

Never use MIDI cables longer than about 15 metres. Cables longer than this can pick up noise which can cause data errors.

CONNECTING TO A PERSONAL COMPUTER

By connecting your W8808A's MIDI terminals to a personal computer, you can have access to a wide variety of music software.


- When using a MIDI interface device installed in the personal computer, connect the MIDI terminals of the personal computer and the W8808A.




- When using a MIDI interface with a Macintosh series computer, please connect the RS-422 terminal of the computer (Modem port or printer terminal) to the MIDI interface, as shown in the diagram below.

NOTICE:

While using Macintosh computers, you have to set the time setting of MIDI interface in the Internet applications the same as the setting of the MIDI interface you are using. Details please refer to the Internet applications instructions.



- When connecting to a computer with a USB interface, just use MIDI interface: first use a standard USB cable to connect Ux16 interface to the computer, and then connect W8808A to UX16 interface correctly.



VOICE LIST

VOICE LIST

The W8808A has 64-note maximum polyphony. This means that it can play a maximum of up to 64 notes at once, regardless of what functions are used. Auto Accompaniment uses a number of the available notes, so when Auto Accompaniment is used the total number of available notes for playing on the keyboard is correspondingly reduced. The same applies to the Split Voice and Song functions.

Caution: The Voice List includes MIDI program change numbers for each voice. Use these program change numbers when playing the W8808A via MIDI from an external device.

Voice No	MIDI No	Name of Voice	中文名称
PIANO 钢琴			
01	0	ACOUSTIC GRAND PIANO	原声大钢琴
02	1	BRIGHT ACOUSTIC PIANO	亮原声钢琴
03	2	ELECTRIC GRAND PIANO	电子大钢琴
04	3	HONKY-TONK PIANO	酒吧钢琴
05	4	ELECTRIC PIANO1	电钢琴1
06	5	ELECTRIC PIANO2	电钢琴2
07	6	HARP	拨弦古钢琴
08	7	CLAV1	击弦古钢琴
CHROMATIC PERCUSSION 打击乐器			
09	8	CELESTA	钢片琴
10	9	GLOCKENSPIEL	钟琴
11	10	MUSIC BOX	音乐盒
12	11	VIBRAPHONE	振琴
13	12	MARINBA	马林巴
14	13	XYLOPHONE	木琴
15	14	TUBULAR BELLS	管钟
16	15	DULCIMER	洋琴
ORGAN 风琴			
17	16	DRAWBAR ORGAN	卓芭风琴
18	17	PERCUSSIVE ORGAN	打击风琴
19	18	ROCK ORGAN	摇滚风琴
20	19	CHURCH ORGAN	教堂风琴
21	20	FEED ORGAN	簧片风琴
22	21	ACCORDION	手风琴
23	22	HARMONICA	口琴
24	23	TANGO ACCORDION	探戈手风琴
GUITAR 吉它			
25	24	ACOUSTIC GUITAR(NYLIN)	尼龙弦吉它
26	25	ACOUSTIC GUITAR(STEEL)	钢弦吉它
27	26	ELECTRNIC GUITAR(JAZZ)	爵士电吉它
28	27	ELECTRNIC GUITAR(CLEAN)	清音电吉它
29	28	ELECTRNIC GUITAR(MUTED)	弱音电吉它
30	29	OVERDRIVEN GUITAR	夸张吉它
31	30	DISTOTION GUITAR	失真吉它
32	31	GUITAR HARMONICS	吉它泛音
BASS 贝司			
33	32	ACOUSTIC BASS	古典贝司
34	33	ELECTRIC BASS(FINGER)	指弹电贝司
35	34	ELECTRIC BASS(PICK)	拨片电贝司
36	35	FRETLESS BASS	无品贝司
37	36	SLAP BASS1	打弦贝司1
38	37	SLAP BASS2	打弦贝司2
39	38	SYNTH BASS1	合成贝司1
40	39	SYNTH BASS2	合成贝司2

Voice No	MIDI NO	Name of Voice	中文名称
STRINGS 弦乐			
41	40	VOLIN	小提琴
42	41	VLOLA	中提琴
43	42	CELLO	大提琴
44	43	CONTRABASS	低音提琴
45	44	TREMOLO ATRINGS	震音弦乐
46	45	PIZZICATO STRINGS	拨奏弦乐
47	46	ORCHESTRAL HARP	竖琴
48	47	TIMPANI	定音鼓
RNSSEMBLE 合奏			
49	48	STRINGS ENSEMBLE1	弦乐合奏1
50	49	STRINGS ENSEMBLE12	弦乐合奏2
51	50	SYNTH STRINGS1	合成弦乐1
52	51	SYNTH STRINGS2	合成弦乐2
53	52	CHOIR AAHS	唱音 啊
54	53	VOICE OOHS	人声 噢
55	54	SYNTH VOICE	合成人声
56	55	ORCHESTRA HIT	管弦乐齐奏
BRASS 铜管			
57	56	TRUMPET	小号
58	57	TROMBONE	长号
59	58	TUBA	大号
60	59	MUTED TRUMPET	弱音小号
61	60	FRENCH HORN	圆号
62	61	BRASS SECTION	铜管乐队
63	62	SYNTH BRASS1	合成铜管乐1
64	63	SYNTH BRASS2	合成铜管乐2
REED 簧管乐器			
65	64	SOPRANO SAX	高音萨克斯
66	65	ALTO SAX	中音萨克斯
67	66	TENOR SAX	次音萨克斯
68	67	BARTION SAX	低音萨克斯
69	68	OBOE	双簧管
70	69	ENGLISH HORN	英国管
71	70	BASSOON	巴松管
72	71	CLARINET	单簧管
PIPE 木管乐器			
73	72	PICCOLO	短笛
74	73	FLUTE	长笛
75	74	RECORDER	竖笛
76	75	PAN FLUTE	排箫
77	76	BLOWN BOTTLE	吹瓶
78	77	SHAKUHACHI	尺八
79	78	WHISTLE	口哨
80	79	OCARINA	奥卡利那笛

VOICE LIST

Voice No	MIDI No	Name of Voice	中文名称
SYNTH REED 合成管乐器			
81	80	LEAD1(WOUIARE)	方波管乐
82	81	LEAD2(SAWTIITH)	锯齿波管乐
83	82	LEAD3(CALLIOPE)	蒸汽琴管乐
84	83	LEAD4(CHIFF)	雪坊管乐
85	84	LEAD5(CHARANG)	沙朗管乐
86	85	LEAD6(VOICE)	人声管乐
87	86	LEAD7(FIFTH)	五度管乐
88	87	LEAD8(BASS+LEAD)	贝司管乐
SYNTH PAD合成背景音色			
89	88	PAD1(NEW AGE)	新世纪垫
90	89	PAD2(WARM)	温暖音色垫
91	90	PAD3(POLYSYNTH)	聚合成音色垫
92	91	PAD4(CHOIR)	唱诗垫
93	92	PAD5(BOWED)	弓弦音色垫
94	93	PAD6(METALLIC)	金属音色垫
95	94	PAD7(HALO)	环形音色垫
96	95	PAD8(SWEEP)	掠扫音色垫
SYNTH EFFECTS合成效果音色			
97	96	FX1(RAIN)	雨
98	97	FX2(SOUNDTRACK)	声轨
99	98	FX3(CRYSTAL)	水晶
100	99	FX4(ATMOSPHERE)	大气
101	100	FX5(BRIGHTNESS)	闪亮
102	101	FX6(GOBLINS)	小妖怪
103	102	FX7(ECHOES)	回声
104	103	FX8(SCO-FI)	科幻
ETHNIC民族乐器			
105	104	SITAR	西塔尔
106	105	BANJO	班卓琴
107	106	SHAMISEN	三弦
108	107	GUZHENG	古筝
109	108	KALIMBA	卡林巴
110	109	BAGPIPE	风笛
111	110	ERHU	二胡
112	111	SUONAI	唢呐
PERCUSSION打击乐器			
113	112	TINKLE BELL	响铃
114	113	AGOGO	啊果果
115	114	STEEL DRUMS	钢鼓
116	115	WOOBLOCK	盒梆
117	116	TAIKO DRUM	日本鼓
118	117	MELODIC TOM	旋律鼓
119	118	SYNTH DRUM	合成鼓
120	119	REVERSE CYMBAL	反钹

Voice No	MIDI No	Name of Voice	中文名称
SOUND EFFECT 效果音色			
121	120	FRET NOSE	弦马杂音
122	121	BREATH NOISE	呼吸音
123	122	SEASHORE	海滨
124	123	BIRD TWEET	小鸟叫声
125	124	TELEPHONE RING	电话铃
126	125	HELICOPTER	直升飞机
127	126	APPLAUSE	喝彩
128	127	GUNSHOT	枪声
FOLK民乐音色			
129	128	YUNLUO	云锣
130	129	GUANMEILANG	甘美郎
131	130	BIANMANG	编铙
132	131	YANGQIN	扬琴
133	132	LUSHENG	芦笙
134	133	PIBA	琵琶
135	134	LUOQIN	柳琴
136	135	YUQIN	月琴
137	136	DARUAN	大阮
138	137	ZHONGRUAN	中阮
139	138	GUOHU	高胡
140	139	ERHU	二胡
141	140	ZHONGHU	中胡
142	141	ERHUQUN1	二胡群1
143	142	ERHUQUN2	二胡群2
144	143	ZHONGHUQUN	中胡群
145	144	BANGDI	梆笛
146	145	KUNDI	昆笛
147	146	XIAO	箫
148	147	BANHU	板胡
149	148	XIPI	西皮
150	149	ZHUIHU	坠胡
151	150	SANXIAN	三弦
152	151	GUZHENG	古筝
153	152	GUOYINSUONA	高音唢呐
PERCUSSION打击乐			
154	153	STANDARD DRUMS	标准鼓组
155	154	CHINESE PERCUSSION	中国打击乐组
156	155	ROOM DRUMS	房间鼓组
157	156	ROCK DRUMS	摇滚鼓组
158	157	ELECTRIC DRUMS	电子鼓组
159	158	T 808 DRUMS	T808鼓组
160	159	JAZZ DRUMS	爵士鼓组
161	160	BRUSH KIT	刷子鼓组
162	161	CLASSIC DRUMS	古典鼓组
163	162	SFX KIT	效果鼓组

STYLE LIST

No	Name	中文名
8/16BEAT 8/16拍		
00	8BEAT-1	8拍1
01	8BEAT-2	8拍2
02	8BEAT-3	8拍3
03	16BEAT-1	16拍1
04	16BEAT-2	16拍2
05	16BEAT-3	16拍3
POP 流行乐		
06	POOPROCK	流行摇滚
07	FOLKROCK	民歌风摇滚
08	POPBOLERO	流行波莱罗
09	POPWALTZ	流行华尔兹
10	SOULBALLAD	流行民谣
11	MOOTOWN	底特律节奏
DANCE 舞曲		
12	HOUSE	家庭舞曲
13	TECHNO-1	现代舞曲1
14	TECHNO-2	现代舞曲2
15	RAVE	拉布
16	DANCE-1	舞曲1
17	DANCE-2	舞曲2
18	DISCO-70S	70年代迪斯科
19	DISCO	迪斯科
20	MACARENA	马卡伦那
R&B 蓝调摇滚		
21	GOSPEL-1	黑人福音音乐1
22	GOSPEL-2	黑人福音音乐2
23	R&B-1	蓝调摇滚1
24	R&B-2	蓝调摇滚2
25	BLUES-1	布鲁斯1
26	BLUES-2	布鲁斯2
27	FUNK	早期爵士乐
ROCK 摇滚乐		
28	ROCK-60S	60年代摇滚
29	ROCK-70S	70年代摇滚
30	ROCK-80S	80年代摇滚
31	BALLROCK	舞会摇滚
32	SLOWROCK	慢摇滚
33	SLOWROCK6/8	慢摇滚6/8
ROCK&ROLL 快速摇滚乐		
34	ROCK&ROLL-1	快速摇滚1
35	ROCK&ROLL-2	快速摇滚2
36	SHUFFLE	滑曳摇滚
37	TWIST	扭扭舞
38	BOOGIE-1	布吉乐1
39	BOOGIE-2	布吉乐2
SWING/JA 摇摆舞/爵士		
40	SWING	摇摆舞
41	LOUNGE	悠闲爵士
42	DIXIE-1	新奥尔良爵士1
43	DIXIE-2	新奥尔良爵士2
44	JAZZBALLAD-1	舞会爵士乐1
45	JAZZBALLAD-2	舞会爵士乐2
46	JAZZWALTZ	爵士华尔兹
47	CHARLSTON	查尔斯顿舞
48	RAGTIME	早期爵士乐
COUNTRY 乡村音乐		

NO	Name	中文名
49	COUNTRY-1	乡村音乐1
50	COUNTRY-2	乡村音乐2
51	COUNTRYDANCE	乡村舞曲
52	COUNTRYROCK	乡村摇滚
53	COUNTRYWALTZ	乡村华尔兹
CARIBBEAN 加勒比音乐		
54	REGGAE-1	雷格1
55	REGGAE-2	雷格2
56	CARIBBEAN	加勒比节奏
LATIN-1 拉丁1		
57	BOSSA-1	波萨诺瓦1
58	BOSSA-2	波萨诺瓦2
59	SAMBA-1	桑巴1
60	SAMBA-2	桑巴2
61	RUMBA	伦巴
62	BEGUINE	贝津舞
63	CHACHA-1	恰恰1
64	CHACHA-2	恰恰2
LATIN-2 拉丁2		
65	SALSA	萨尔萨舞曲
66	CUMBIA	巴西舞曲
67	MERENQUE	美伦格舞
68	MAMBO	曼波舞曲
69	LATIN	拉丁舞曲
70	GIPSY	吉普赛舞
71	D.SAMBA	迪斯科桑巴
ORIENTAL 东方舞曲		
72	CINGENE	阿拉伯舞曲
73	MUS5/8	土耳其舞曲
74	ORIENTAL	东方舞曲
75	OYUNHAVA	小亚细亚舞曲
WORLD MUSIC 世界音乐		
76	SEVILLIANA	赛尔维利亚舞曲
77	HOLLYWOOD	好莱坞
78	SP.RUMBA	西班牙伦巴
79	SP.BOLERO	西班牙波莱多
80	SIRTAKI	希腊舞曲
81	BAROQUE	巴洛克
82	HAWAII	夏威夷舞曲
BALLROOM 交谊舞曲		
83	FOXTROT	狐步舞曲
84	QUICKSTEP	快步舞
85	SLOWFOX	慢狐步舞
86	TRAD.WALTZ	传统华尔兹
87	JIVE	轻快爵士
88	PASODOBLE	平舞土舞
89	TANGO	探戈
90	TANGOARG	阿根廷探戈
WALTZ/MARCH 华尔兹进行曲		
91	GERMWALTZ	德国华尔兹
92	VIENNAWALTZ	维也纳华尔兹
93	MUSETTE	风笛舞
94	SLOWWALTZ	慢速华尔兹
95	MARCH	进行曲
96	MARCH6/8	进行曲6/8
97	POLKA	波尔卡
98	D.POLKA	迪斯科波尔卡
99	SCHLAGER	德国进行曲

DRUM SET TABLE (MIDI CHANNEL 10)

	6 HQ TR808 SET	7 HQ DANCE SET	8 BRUSH	9 ORCHESTRA	10 SFX SET
39 - D#2				Closed Hi Hat	*
40 - E2				Pedal Hi-Hat	*
41 - F2				Open Hi Hat	*
42 - F#2				Ride Cymbal	*
43 - G2					*
44 - G#2					*
45 - A2					*
46 - A#2					*
47 - B2	HQ 909 BD	HQ Dance Kick	Jazz BD2	Concert BD 2	*
48 - C3	HQ 808 BD	HQ Elec Kick2	Jazz BD1	Concert BD 1	*
49 - C#3	808 Rim shot				*
50 - D3	808 Snare Drum	HQ Dance snare1	Brush Tap	Concert SD	*
51 - D#3			Brush Slap	Castanets	High Q
52 - E3	HQ 909 Snare	HQ Dance snare2	Brush Swirl	Concert SD	Slap
53 - F3	808 Low Tom2	Elec Low Tom2		Timpani F	Scratch Push
54 - F#3	808 CHH [EXC1]	808 CHH [EXC1]		Timpani F#	Scratch Pull
55 - G3	808 Low Tom2	Elec Low Tom1		Timpani G	Sticks
56 - G#3	808 CHH [EXC1]	808 CHH [EXC1]		Timpani G#	Square Click
57 - A3	808 Mid Tom2	Elec Mid Tom2		Timpani A	Metronome Click
58 - A#3	808 OHH [EXC1]	808 OHH [EXC1]		Timpani A#	Metronome Bell
59 - B3	808 Mid Tom1	Elec Mid Tom1		Timpani B	Guitar Slide
60 - C4	808 Hi Tom2	Elec Hi Tom2		Timpani c	Gt Cut Noise (down)
61 - C#4	808 Cymbal			Timpani c#	Gt Cut Noise (up)
62 - D4	808 HiTom1	Elec Hi Tom1		Timpani d	Double Bass Slap
63 - D#4				Timpani d#	Key Click
64 - E4		Reverse Cymbal		Timpani e	Laughing
65 - F4				Timpani f	Screaming
66 - F#4					Punch
67 - G4					Heart Beat
68 - G#4	808 Cowbell				Footsteps1
69 - A4				Concert Cymbal2	Footsteps2
70 - A#4					Applause
71 - B4				Concert Cymbal1	Door Creaking
72 - C5					Door Closing
73 - C#5					Scratch
74 - D5	808 High Conga				Wind Chime
75 - D#5	808 Mid Conga				Car Engine Start
76 - E5	808 Low Conga				Car Breaking
77 - F5					Car Pass
78 - F#5					Car Crash
79 - G5					Police Siren
80 - G#5					Train
81 - A5					Jet Take-off
82 - A#5	808 Maracas				Helicopter
83 - B5					Starship
84 - C6					Gun Shot
85 - C#6					Machinegun
86 - D6					Lasergun
87 - D#6	808 Claves				Explosion
88 - E6					Dog
89 F6					Horse Gallop
90 - F#6					Birds
91 G6					Rain
92 - G#6					Thunder
93 A6					Wind
94 - A#6					Sea Shore
95 B6					Stream
96 C7					Bubble
					*
					*
					*
					*

FUNCTION PARAMETERS

TYPE		DISPLAY	RANGE/ SETTING	INSTRUCTION
Pitch bend Roller		PITCHBEND	+/- 12 semitones	It is used to simulate the pitch bend of natural instruments.
Touch Response		Grade 1		A very sensitive response is suitable for large range of dynamic performance. When playing on the keyboard with high strength, it voice with maximum volume.
		Grade 3		A medium touch response.
		Grade 5		A modest response. When playing with high strength or low strength, the difference is quite limited.
Reverb		REVERB	01-08	It determines the Reverb Type, and its ON/OFF.
Tuning		TUNING	+/- 100 (ca. +/- 1 semitone)	It determines all the volume pitch of W8808A
Transpose		TRANSPOSE	+/- 12 semitones	It determines all the transpose of W8808A
Harmony		HARMONY	00-08	It determines the harmony type and its ON/OFF.
Accompaniment volume		ACMP VOLUME	0-127	It determines the accompaniment volume of W8808A
	Style Mode		40-240	It determines the accompaniment tempo of W8808A , in order to make it suitable for your performance.
	Song Mode		40-240	It determines the tempo of demo songs.
MIDI	The ON/ OFF of this instrument	LOCAL	ON/OFF	It determines the ON/OFF of this instrument. Press [+ / YES] and [- / NO] to turn on / off this instrument.
	External Clock	EXTERNAL	ON/OFF	It determines external or internal clock. Press [+ / YES] and [- / NO] to turn on / off the external clock.
	Transmitting Initial Setting	INIT SEND		It allows you save the initial data to other data (e.g. sequencer, computer or MIDI files). Press [+ / YES] to send the data out; press [- / NO] to stop sending out.
	Transmitting Bulks of Information	BULKDUMP		It allows you save the important data to other data (e.g. sequencer, computer or MIDI files). Press [+ / YES] to send the data out; press [- / NO] to stop sending out.

TROUBLESHOOTING

Problems	Possible Causes and Solutions
When the W8808A is turned on or off, a popping sound is temporarily produced.	This is normal and indicates that this instrument is receiving electrical power.
When using a mobile phone, noise is produced.	Using a mobile phone in close proximity to the W8808A may produce interference. To prevent this, turn off the mobile phone or use it further away from the W8808A.
There is no sound even when the keyboard is played or when a song is being played back.	Check that nothing is connected to the PHONES/OUTPUT jack on the rear panel. When a set of headphones is plugged into this jack, no sound is output.
The sound of the voices or rhythms seems unusual or strange	The battery power is too low. Replace the batteries.
The accompaniment does not sound properly.	Make sure that the Accompaniment Volume is set to an appropriate level.
The voice chosen does not sound properly, or the volume is too low.	Make sure the settings are appropriate: master volume, dual balance
Not all of the voices seem to sound, or the sound seems to be cut off.	The W8808A is polyphonic up to a maximum of 64 notes. If the Dual voice is being used and a style or song is playing back at the same time, some notes/sounds may be omitted (or "stolen") from the accompaniment or song.
The sound of a voice changes from note to note.	This is normal. The AWM tone generation method uses multiple recordings (samples) of an instrument across the range of the keyboard; thus, the actual sound of the voice may be slightly different from note to note.
The foot switch (for sustain) seems to produce the opposite effect. For example, pressing the foot switch cuts off the sound and releasing it sustains the sounds.	The polarity of the foot switch is reversed. Make sure that the foot switch plug is properly connected to the SUSTAIN jack before turning on the power.

TECHNICAL SPECIFICATIONS

Keyboard

88-key keyboard with hammer action

Voice

348 PCM voices

Max polyphony: 64 notes

Keyboard percussion: 1~9 groups

Sound effect: 1 group

Volume: 00~27

Octachord: -2~2

Phase: -7~7

Keyboard Split: left & right hand voice

Dual: right hand voice1, left hand voice2

Harmony and echo: 10 styles

DSP reverb styles: 8 styles

DSP chorus styles: 8 styles

DSP reverb and chorus send level:
00~127

DSP reverb and chorus return level:
00~127

Auto Accompaniment Function

100 styles

Accompaniment track: rhythm, bass,
rhythmic chord, long chord, sentence 1/2

Large & small accompaniment mode

Accompaniment track setting: ON / OFF,
voice, volume

Accompaniment control: SYNCHRO,
Intro, Main A & B, Auto Fill A & B, ending,
start / stop

Tempo: 40~240

Accompaniment volume: 00~127

Accompaniment split

Songs

22 demo songs and 5 user songs

Record Track

5 record tracks

Accompaniment Mode

Normal Performance, keyboard split,
single finger, fingered

Panel Parameter Memory Bank

8 banks, accompaniment freeze

Total Function

Transpose: -12~+12

Metronome: ON & OFF

Display

122 * 50mm large LCD screen

Control Buttons

Up & down & right & left cursors, up &
down function buttons, mode button,
numeric buttons 0~9

MIDI function: receive and send

Auxiliary Interfaces

AC input, earphone, foot switch

MIDI IN & OUT

Power Output

10W+10W

Earphone output: resistance output-32
ohm

Loudspeaker: 16.5cm*2+5cm*2, 4 ohm

Voltage: 220V AC

Packing Information

Dimension: 1500(L)*650(W)*450(H)mm

G. W.: 75kg

N. W.: 70kg

Complimentary Accessories


Screws, screw caps, screw washers

Power supply cable

Owners manual

Warranty card

The specifications are subject to change without notice.



W8808A OWNER'S MANUAL

Owner's Manual