

WORLDE MIDI键盘控制器号设置教程

MIDI键盘型号 EASYKEY **面板控制** **初始控制器号**

The screenshot displays the 'Editor' window of the WORLDE MIDI software. The interface is divided into three main sections: 'MIDI键盘型号 EASYKEY', '面板控制', and '初始控制器号'. The central part of the window shows a virtual keyboard with various MIDI Control Change (CC) numbers assigned to specific keys. A 'CONTROL' panel is open at the bottom, showing settings for 'Key - 4'. The 'CC Number' field is set to 15, and the 'On Value' field is set to 127. The 'Key Enable' dropdown is set to 'Enable', and the 'Key Behavior' dropdown is set to 'Momentary'. A 'CC Number' dropdown menu is also visible in the top right of the control panel area.

Key	CC Number
Key - 1	12
Key - 2	13
Key - 3	14
Key - 4	15
Key - 5	16
Key - 6	17
Key - 7	18
Key - 8	19
Key - 9	20
Key - 10	21
Key - 11	22
Key - 12	23
Key - 13	24
Key - 14	25
Key - 15	26
Key - 16	27
Key - 17	28
Key - 18	29
Key - 19	30
Key - 20	31
Key - 21	80
Key - 22	81
Key - 23	82
Key - 24	84
Key - 25	85

CONTROL

Common
Keyboard
Key - 1
Key - 2
Key - 3
Key - 4
Key - 5
Key - 6
Key - 7
Key - 8

Key Enable: Enable
Key Behavior: Momentary
CC Number: 15
On Value: 127

CC Number



WORLDE MIDI键盘控制器号设置说明

1) WORLDE MIDI键盘支持所有通用MIDI格式的应用软件，如您在初次使用WORLDE MIDI键盘时遇到因控制器号不匹配而无法成功连接应用软件的问题，请参考本说明对应用软件的控制器号进行设置。如：WORLDE KS49A的SLIDER推杆的初始控制器号为147，若您欲将此SLIDER推杆和应用软件上的某个SLIDER推杆成功匹配，您需要先将应用软件上这个SLIDER推杆的控制器号设置为147。

2) 由于MIDI协议规定的控制器号范围为0到127，如需使初始控制器号超过127的面板控制与应用软件成功匹配，您需要先将此面板控制的控制器号更改为0到127之间的控制器号，然后使用和上述1同样的方式使此面板控制成功匹配应用软件。如：WORLDE KS49A的SLIDER推杆的初始控制器号为147，您需要先将此SLIDER推杆的控制器号更改为0到127之间的控制器号，然后再将应用软件上相对应的SLIDER推杆的控制器号更改为与此相同的控制器号即可。